



Specialist for Pumping Technology

**Session 28 – NPSH &
Nss Made Simple
(well, Simpler Anyway!)**

Simon Smith November 2023





Presenter Profile – Simon Smith

Simon graduated with an honours degree in Chemical Engineering from the University of Surrey in 1978 and began a long career in the engineered pump industry spanning 40 years (so far!) with Peerless Pump, BW/IP International / Flowserve, SPP Pumps, Ruhrpumpen and Ebara Cryodynamics.

Over his long career he has filled various roles as Applications Engineer / Manager, Project Manager, Key Account Specialist, Vertical Pump Product Specialist, International Sales Engineer / Manager / Director and he has considerable experience in Training & Mentoring young engineers.





RuhrPumpen Short Courses

Here is a listing of all the previous courses.

- No 1 – API610 12th v 11th editions
- No 2 - Curve Shape
- No 3 – The Importance of System Curves (1)
- No 4 - Selecting the Right Pump for the Application
- No 5 - NPSH & Nss
- No 6 - Mechanical Seals & Systems (1)
- No 7 - Firepumps
- No 8 - BB5 Barrel Pumps
- No 9 - Pump Instrumentation
- No 10 – Non-Destructive Examination
- No 11 - Vertical Pumps (Part 1) Type VS1, VS2, VS3
- No 12 – Vertical Pumps (Part 2) Type VS4, VS5, VS6 & VS7
- No 13 – Performance Testing of Centrifugal Pumps; the What, the Why & the How
- No 14 – Testing & Inspection of API 610 Pumps
- No 15 – Start-Up, Commissioning & Troubleshooting Centrifugal Pumps
- No 16 – Introduction to Positive Displacement (Plunger) Pumps
- No 17 – Refresher Session
- No 18 – Overhung Process Pumps OH1 & OH2
- No 19 – Vertical Overhung Process Pumps OH3-OH6
- No 20 – New Developments in the VS6 Market
- No 21 – BB4 Multistage Pumps for the Power Industry
- No 22 – Coking Process and Hydraulic Decoking Equipment
- No 23 – Pumps for the Desalination Market
- No 24 – Cryogenic Pumps
- No 25 – Magnetic Drive Pumps
- No 26 – Mechanical Seals & Systems (2)
- No 27 – The Importance of System Curves (2)

Any you have missed you can get from our website using this link <https://short-courses.ruhrpumpen.com/>

Or from www.ruhrpumpen.com and follow the link to [RP Short Courses](#)



RuhRPumpen Short Courses

www.ruhrpumpen.com



More Articles

- Introducing the new Ruhrpumpen Website
- Impeller Lift Procedure
- Newsletter Ruhrpumpen Fire Systems - December 2022
- VTP pumps for major water transfer project in Bolivia
- COVID-19 UPDATE
- Introducing the RP ANSI Process Pump Range
- Ruhrpumpen Resources
- Coolant System Maintenance
- RP delivers API 674 pumps for Gas Dehydration Package in Algeria
- Packing strips and packing gland tightening procedure

All Courses

Don't miss our **short course #25**

COMING SOON



Simon Smith
Solutions Expert

QUALITY
INNOVATION
EFFICIENCY



RuhRPumpen Short Courses

<https://short-courses.ruhrpumpen.com/>

SHORT COURSE 12

Vertical Pumps (VS4/5, VS6, VS7)

Full session.

 Downloads. (14.73 MB)

SHORT COURSE 13

Performance Testing and Inspection of API 610 Pumps

Full session.

 Downloads. (4.58 MB)

SHORT COURSE 14

Performance Testing and Inspection of API 610 Pumps


Full session.

 Downloads. (7.30 MB)



RuhRPumpen Short Courses

<https://short-courses.ruhrpumpen.com/>



SHORT COURSE 14

Performance Testing and Inspection of API 610 Pumps

Full session.

 Downloads. (7.30 MB)

SHORT COURSE 15

Start-Up, Commissioning & Troubleshooting Centrifugal Pumps

Full session.

 Downloads. (6.14 MB)

SHORT COURSE 16

Introduction to Positive Displacement (Plunger) Pumps

Session part 1.

Session Part 2.

 Downloads. (10.50 MB)



Session 28 – “NPSH & Nss Made Simple (well, Simpler Anyway!)”

Aimed at Process and Mechanical Engineers and Consultant Engineers specifying pumping equipment as well as Applications & Sales Engineers selecting and quoting them. Develop an understanding of the fundamentals and practical aspects of NPSH – probably the most difficult and misunderstood concept in pumping

Will cover such topics as Cavitation damage, Suction Specific Speed and the “11,000 limitation”, and understanding the NPSH Curve



NPSH Made Simple

Contents

1. $NPSH_A$
2. $NPSH_{R \text{ or } 3}$
 1. What it is
 2. How we measure and test for it
3. Cavitation
 1. NPSH induced Cavitation
 2. Low Flow Recirculation induced Cavitation (suction & discharge)
4. Suction Specific Speed (N_{SS})
 1. What it is
 2. The 11,000 limitation



1 – NPSH_A



NPSH_A

What it is.

At any given temperature, all liquids have a definite pressure at which they boil. Every day we witness the fact that a liquid boils at atmospheric pressure when it reaches a sufficiently high temperature. It is important to remember also that a liquid will boil at any temperature if the pressure is reduced sufficiently. While at sea level water boils at 100⁰C (212⁰F) at the top of Mount Everest it boils at 68⁰C (154⁰F)

It is the problem of the Process & Applications Engineers to make certain that there is enough pressure on the fluid being fed to the pump so that the liquid does not boil in the suction of the pump.



NPSH_A

Definition

Net

Positive (means head over and above the vapour pressure)

Suction (at the suction flange / centreline of impeller)

Head

Available

“The net positive suction head available is the total suction head in feet (meters) of liquid absolute determined at the suction flange, minus the vapour pressure of the liquid in feet (meters) absolute”

$$\text{NPSHA} = \text{Suction Pressure (ft or m)} - \text{Vapour Pressure (ft or m)}$$



NPSH_A

Arithmetically:-

$$\text{NPSHA} = H_a - H_{\text{vpa}} \pm H_{\text{st}} - H_f$$

Where:-

H_a = the head from the absolute pressure acting on the surface of the liquid

(in an open suction system this will be atmospheric pressure, in a closed system it will be the pressure in the suction vessel acting on the surface of the liquid)

H_{vpa} = the head from vapour pressure (always a negative value)

H_{st} = Static head above the pump impeller centerline (suction flange)

(this value is negative in the case of a suction lift)

H_f = Friction head in pipework (always a negative value)



2 – NPSH_R

2.1 – What it is



NPSH_R (or 3 or 1)

Definition

Net

Positive (means head over and above the vapour pressure)

Suction (at the suction flange / centreline of impeller)

Head

Required (historically by convention the same as NPSH₃)

NPSH₃ is measured and defined as a **3%** reduction of pump TDH

NPSH₁ is measured and defined as a **1%** reduction of pump TDH

“NPSHR is the total suction head in feet (meters) of liquid absolute measured at the suction flange / centreline of the impeller that corresponds to a 3% (sometimes 1%) reduction in discharge pressure.”



NPSH_R

Why a Pump Requires a Positive Suction Head

A pressure drop occurs between the pump suction flange and the minimum pressure point within the pump impeller because of:

- 1- An increase in the velocity between the suction flange and entrance to the impeller vanes.
- 2- Friction & turbulence between the suction flange and the entrance to the impeller vanes


It is impossible to design a centrifugal pump in which there is no pressure drop between the suction flange and the entrance to the impeller vanes.

All pump systems must have a positive suction head sufficiently high to overcome this pressure drop within the pump and to **keep the fluid from boiling at the pumping temperature.**



NPSH_R

Visually



$$\text{NPSH Margin} = \text{NPSHA} - \text{NPSH3}$$

GOLDEN RULE:-

Per ASME B73 & HI, the NPSHA must always exceed the NPSH3, by 3Ft (1m) or by 1.2 x (NPSHA/NPSH3).




2.2 – NPSH Testing



NPSH_R


Typical Pump Test Loop





NPSH_R

NPSHR Testing Procedure






NPSH_R

NPSHR Testing Procedure

- The pump is set to the rated speed.
- At each flow point (typically 5 or 6 flows), while the Suction Pressure is reduced, the Discharge Valve is opened slightly to maintain the constant set Flowrate.
- At each NPSHR Test point, Flow, Head, Suction pressure & Water Temperature readings are taken at progressively lower and lower Suction pressures. Whether the reduction in Suction pressure is due to a Vacuum Suppression Test or a Throttled Suction valve Test.
- At some point, as the Suction Pressure is reduced more and more, the Pump Differential Head will get closer to a 3% Head reduction. So now the Suction Pressure Reduction values are taken closer together.
- After the Head drop has reached 3% at every Flowrate, the NPSH3 test is completed.



NPSH_R NPSH Test Curve





NPSH_R

Common Misconception

"Suction cavitation occurs when NPSHa (available) is less than NPSHr (required)."

This is completely **wrong** and a misunderstanding of the physics involved in a centrifugal pump. Here is why:


- Consider that NPSHr is normally determined where the pump head has already degraded by 3%. By that point there is already extensively developed cavitation in the impeller.
- Simply raising NPSHa slightly above NPSHr does not result in that cavitation magically disappearing. You need to go to much higher suction pressures to completely eliminate cavitation.
- For an "average" centrifugal pump, to **completely** eliminate cavitation, the NPSHa would need to be >500% of the NPSHr (specifically the NPSHi point shown on the example below).

Source – Simon Bradshaw - Director Engineering, Pumps Americas at CIRCOR



NPSH_R

Onset of Cavitation



All pumps operate with suction cavitation. The only question is whether it is damaging cavitation.



3 – Cavitation

3.1 – NPSH Cavitation




Cavitation

As the suction head value gets closer to the $NPSH_3$ value, vapour bubbles form on the underside of the inlet vanes of the impeller.

The closer you get to the $NPSH_3$ value the more bubbles will form and over a larger area of vane.

As these bubbles are swept into higher pressure areas they collapse with a shock





Cavitation

The Cavitation Mechanism

When a Cavitation vapour bubble collapses, the instantaneous pressure of this small, high energy shock-wave is many thousands of PSI over an extremely small area.

There are two progressive shock waves that impact the metal surface against the bubbles:-

The initial MICRO-JET formed when the top surface of the bubble starts to collapse.

Immediately after this micro-jet, the whole surface of the bubble then collapses & returns to liquid form.

Shock waves are formed by collisions among the surrounding liquid molecules, that rush in to fill the void caused by the collapsing bubble.


Research has shown that the life span of a Cavitation bubble from formation to collapse, is about two milliseconds (two one-thousands of a second), so this event occurs very rapidly.

The more rapidly the surrounding Liquid collides, the greater is the energy of the damaging shock-wave & micro-jet.




Cavitation

The Cavitation Mechanism



This illustration shows the progression of the vapor bubble collapse.

These ultra-high speed Laboratory photos below show this progression:-



Below is a photo showing the micro-burst jet, just before the final collapse:-





Cavitation

Extent of the Damage

The extent of the damage will depend on several factors:

- The size of the bubbles formed
- The Density of the fluid
- Thermodynamic effects (Enthalpy & Latent heat)

These combined effects comprise “Thermal Cavitation Criteria –B” (see next slide)

But simply put:

- Cold water forms big bubbles and has a high density, so the damage done when the bubbles collapse is high
- Hydrocarbons form small bubbles and have a lower density, so the damage done when the bubbles collapse is much less



Cavitation

Extent of the Damage – in More Detail

COMPARITIVE VALUES OF THE THERMAL CAVITATION CRITERIA-B:-

Below we show a list of the various **THERMAL CAVITATION CRITERIA-B** values for Water which exhibits high cavitation damage, and Butane, a light hydrocarbon, which usually exhibits a much lower cavitation damage rate.

<u>Thermal Cavitation</u>	Water	Water	Water	Water	Butane
<u>Criteria B</u>	<u>70F</u>	<u>180F</u>	<u>212F</u>	<u>300F</u>	<u>70F</u>
<u>Value of B</u>	253	1.048	0.324	0.0223	0.0202

This shows why one of the worst liquids to produce damaging cavitation erosion is COLD WATER. As this has a very high ratio of vapour to liquid and a high density (relative to hydrocarbons which increases the kinetic energy of the cavitation micro-jet causing the erosion damage.



Cavitation

Hydrocarbon Correction Factor

Allowed by HI

Not allowed by API since 6th edition




Fig. 61 NPSH REDUCTIONS FOR PUMPS HANDLING HYDROCARBON LIQUIDS AND HIGH TEMPERATURE WATER

Note: This chart has been constructed from test data obtained using the liquids shown. For applicability to other liquids refer to the text.



Cavitation

NPSH Suggested Margins

ANSI / Hydraulic Institute Standard Para 9.6.1 addresses NPSH Margin

API Pumps in hydrocarbon service

NPSH Margin ($NPSH_A / NPSH_3$) = 1.1 or 1m (3.3ft)

in the allowable operating range (AOR)

Chemical Process Pumps

with $N_{ss} < 11,000$, NPSH Margin ($NPSH_A / NPSH_3$) = 1.1 or 0.6m (2ft)

with $N_{ss} > 11,000$, NPSH Margin ($NPSH_A / NPSH_3$) = 1.2 or 1.0m (3.3ft)

in the allowable operating range (AOR).



3 – Cavitation

3.2 – Low Flow Induced Cavitation

Suction & Discharge Recirculation




Suction & Discharge Recirculation

A Different kind of Cavitation

Occurs when pumps operate back on the curve from BEP

When two flow paths within a fluid are moving in opposing directions and in close proximity to each other, vortices form.

These vortices result in low pressure areas (where bubbles form) and high pressure areas (where they collapse).




Recirculation vortices at impeller suction eye and at vane tips (source: Handbook, Igor J. Karassik and Joseph P. Messina; ISBN-10 007033)

Suction Recirculation


A Different kind of Cavitation

Suction Recirculation Cavitation Damage appears on back side (pressure side) of vane



NPSH Cavitation Damage appears on front side (suction side) of vane

Suction Recirculation Cavitation Damage appears on back side (pressure side) of vane. You need a dentist's mirror to see it under here.





Discharge Recirculation

A Different kind of Cavitation



The central core of the Discharge Recirculation Vortex, is such a low pressure that the liquid starts to vapourise & as the bubbles move to the outer area of the vortex, where the pressure is much higher, they Cavitate (implode) against the Impeller Shrouds, and cause the hole damage shown.



Cavitation – Which Type Have I Got?

The quickest and easiest way to identify the real cause of the noise, loss of performance, reduced power & vibration, is merely to throttle the discharge valve...

This will cause the pump flow to reduce, so that one of three events will occur, which allows the true cause to be found:-

Event 1:- If the rumbling & rattling sound reduces, or in fact may be eliminated entirely....

*The pump is now running at a lower flow with lower NPSHR requirements. **So this event indicates that NPSH Cavitation was the real culprit.***

Event 2:- If the rumbling & rattling sound, and the vibration increases.....

*This tells us that the pump is moving into a lower flow condition causing the situation to get worse. **So this event indicates that Suction and/or Discharge recirculation was the real culprit.***

Event 3:- OR- If the result, is that there is no change in the sound or vibration.....

*This tells us the events are unaffected by flow. **So this event indicates that Air or Gas entrainment in the Liquid was the real culprit.***



Cavitation Damage

How can I Minimise or Mitigate the Damage?

THE FOLLOWING MATERIALS ARE PROGRESSIVELY MORE RESISTANT TO EROSION & CAVITATION DAMAGE. STARTING WITH CAST IRON AS THE LEAST RESISTANT:-

1. Cast Iron..... Least Resistant.
2. Leaded Bronze.
3. Cast Carbon Steel.
4. Manganese Bronze.
5. Monel.
6. Chrome and Stainless Steels:-
 CA15 & **CA6NM (Martensitic)** & CF8M (Austenitic).
7. Cast Duplex Stainless Steels.
8. Cast Nickel Aluminum Bronze.
9. Alloyed Titanium.
10. Cast Carburized 12% Chromium Stainless and Chrome Manganese
 Austenitic Steels.....Very Resistant.
11. Stellite coating.....Most Resistant.



4 – Suction Specific Speed & the 11,000 limitation



Suction Specific Speed (N_{SS})

Definition

You may think of it as a dimensionless number * that describes the NPSH capability of an impeller

Defined as:-

$$NSS = N(\text{RPM}) \times Q(\text{BEP Full Dia})^{0.5} / \text{NPSH}(\text{BEP Full Dia})^{0.75}$$

$$\text{NSS}(\text{Metric}) = \text{NSS}(\text{US}) \times 1.16 \text{ (m}^3/\text{hr, m, rpm)}$$

Almost universally expressed in USGPM, Ft, RPM units

The higher the number the lower the NPSH_R

Most specifications limit the allowable value to 11,000 (US units) or 12,760 (m³/hr, m, rpm)

WHY?

* Except that it isn't actually dimensionless!



Suction Specific Speed (N_{ss})

The 11,000 Limit

In the 1950's to 1980's the impeller design methods available to pump designers were more limited than they are today. Impeller designs from that era were notable for their achievement of good suction performance through the deployment of large impeller inlet diameters. It was not understood until later that the enlarging of the impeller inlet diameter caused impairment of the impeller performance at flow rates lower than the best efficiency point (BEP). This impairment exhibited itself as significantly increased vibration, Suction Recirculation, and in some extreme cases an unstable NPSHr characteristic.

- Warren Fraser – “Flow Recirculation in Centrifugal Pumps” (1981)

<https://oaktrust.library.tamu.edu/handle/1969.1/163728>

In 1981 Warren Fraser published a paper which brought the consequences of relying on large impeller inlet diameters into focus.

Pump users had already become increasingly concerned that while such designs minimized plant 1st cost, it was at the price of reliability and overall life cycle cost.



Suction Specific Speed (N_{ss})

The 11,000 Limit

- Jerry Hallam – “Centrifugal Pumps: Which Suction Specific Speeds are Acceptable?”, Hydrocarbon Processing, April 1982

In 1982 Jerry Hallam published the results of a large scale reliability study of 480 pumps over a 5 year period at the Amoco Texas City refinery. He found that the reliability of a pump was meaningfully related to its suction specific speed (N_{ss}). Specifically pumps with a $N_{ss} > 11,000$ ($S > 12760$) failed twice as often compared to lower suction specific speed pumps.

Hallam concluded: "This study indicates that caution should be exercised when purchasing hydrocarbon or small water pumps with a N_{ss} greater than 11,000 unless operation is closely controlled near BEP."



Suction Specific Speed (N_{ss})

The 11,000 Limit

- Lobanoff & Ross, “Centrifugal Pumps: Design & Application 2nd Edition Fig 8-7”

Lobanoff & Ross carried out testing in 1985 which supported this limitation based on the then current state of impeller design.

They tested a range of impellers with differing suction specific speeds from $N_{ss} = 7000$ to $N_{ss} = 20,000$. For each impeller the flow was varied until the pump vibration level exceeded the API 610 allowable level of 0.3 inches/sec (7.6 mm/s) peak.

The testing showed a strong correlation of N_{ss} & vibration.

The limit of 11,000 was widely adopted as a hard limit in the oil and gas industry and it is still rare to see a specification that does not invoke it.



Suction Specific Speed (N_{ss})

The 11,000 Limit

Impeller design has improved by leaps and bounds since the 1980s and many authors have published papers to this effect.

Central to their claim was the premise that modern impeller design techniques allowed the attainment of better NPSH performance (and hence higher N_{ss} values) without relying solely on enlargement of the impeller eye.

- Bradshaw, Simon; Cowan, David; Liebner, Thomas (2013). “Influence Of Impeller Suction Specific Speed On Vibration Performance.”

<https://oaktrust.library.tamu.edu/handle/1969.1/162554>

In 2013 Bradshaw, Cowan & Liebner of ITT Goulds repeated the Lobanoff & Ross study from 1985 using modern impeller designs and pump construction standards. It is a very interesting read and I would recommend it to you all. I provide a link at the end of this presentation.

It would certainly suggest a limit of 13,000 rather than 11,000 and probably as high as 14,776.



Sources & References

1- Simon Bradshaw - Director Engineering, Pumps Americas at CIRCOR, formerly Sulzer Pumps & ITT Goulds Pumps

“No You Can’t Prevent Cavitation”

<https://www.linkedin.com/pulse/you-cant-prevent-cavitation-simon-bradshaw/?trackingId=T9h7yxZWQFmQiQJ3IISIPA%3D%3D>

2- Ian James – Engineering Manager variously at David Brown Bingham, Dresser Rand, HMD Pumps, RuhRPumpen, Best Pump Works, AMEC, and DXP & Pumpworks.

3- Warren Fraser – “Flow Recirculation in Centrifugal Pumps” (1981)

<https://oaktrust.library.tamu.edu/handle/1969.1/163728>



Sources & References

4- Jerry Hallam – “Centrifugal Pumps: Which Suction Specific Speeds are Acceptable?”, Hydrocarbon Processing, April 1982

5- Lobanoff & Ross, “Centrifugal Pumps: Design & Application 2nd Edition Fig 8-7”

6- Bradshaw, Simon; Cowan, David; Liebner, Thomas (2013). “Influence Of Impeller Suction Specific Speed On Vibration Performance.”

<https://oaktrust.library.tamu.edu/handle/1969.1/162554>

7- Hirschberger, M., James, I., 2009, A Review of Nss Limitations – New Opportunities, Proceedings of the 25th International Pump Users Symposium, 2009



Coming Attractions 😊

“The Impact of Curve Shape, Head-Rise to Shutoff and “Zero Tolerances” on Equipment Selection, Reliability, & Pricing”

Thurs 12th January – 08.00 (UK GMT) (Eastern Hemisphere) & 17.00 (UK GMT) (Western Hemisphere)

Aimed at Process and Mechanical Engineers and Consultant Engineers specifying pumping equipment. The (wrong) assumption that pumps should all have a 10-15% head rise to shutoff can lead to the oversizing of pump and motor equipment, and subsequent poor performance in the field. This presentation will help engineers to specify the right pump for the application.

Future subjects in preparation include:

- API610 12th Edition

The logo consists of a white circle with a stylized white symbol inside, resembling a triangle or a pump handle. The word "RUHRPUMPEN" is written in a bold, white, sans-serif font across the middle of the circle.

RUHRPUMPEN

Specialist for Pumping Technology

Q & A

www.ruhrpumpen.com

marketing@ruhrpumpen.com

RUHRPUMPEN AT A GLANCE

**VERTICAL
INTEGRATION**

**SALES
OFFICES IN
+35 COUNTRIES**

**MANUFACTURING
FACILITIES
IN 10 COUNTRIES**


**+70 YEARS
OF EXPERIENCE**

**+2,000
EMPLOYEES**

**15 SERVICE
CENTERS**

+70,000 PUMPING SOLUTIONS INSTALLED WORLDWIDE

A GLOBAL COMPANY



MARKETS WE SERVE

Our commitment to create innovations that offer reliable solutions to our customers allow us to provide a complete range of pump systems to support **core markets** as:



OIL & GAS



CHEMICAL



INDUSTRIAL



POWER



WATER



OUR PUMP LINES

Ruhrpumpen offers a broad range of highly engineered and standard pumping products that meet and exceed the requirements of the most demanding quality specifications and industry standards.

Our pumps can handle head requirements as high as 13,000 ft (4,000 m) and capacities up to 300,000 gpm (68,000 m³/hr). Moreover, our pump designs cover temperatures from cryogenic temperatures of -310 °F (-196 °C) up to 752 °F (400 °C).

Products include:



- Single Stage Overhung Pumps
- Between Bearings Pumps
- Horizontal Multi-Stage Pumps
- Vertical Multi-Stage Pumps
- Vertical Mixed Flow & Axial Flow Pumps
- Positive Displacement Pumps
- Full Range of Industrial Pumps
- Submersible Pumps
- Magnetic Drive Pumps
- Decoking Systems
- Packaged Systems
- Fire Systems





OUR PUMPS


OVERHUNG PUMPS

CATEGORY	RP MODEL	DESIGN STANDARD	
Sealless Magnetic Drive Pumps	CRP-M / CRP-M-CC	ISO 2858 & 15783 HI design (OH11)	
	SCE-M	API 685	
Foot Mounted OH1 and General End Suction Pumps	IPP	HI design (OH1)	
	CPP / CPP-L	HI design (OH1) ANSI B73.1	
	CPO / CPO-L	HI design (OH1) ANSI B73.1	
	CRP	HI design (OH1) ISO 2858 & 5199	
	GSD	HI design (OH0)	
	SHD / ESK / SK / SKO SKV / ST / STV	HI design (OH1)	
	SWP	HI design (OH3A)	
Centerline Mounted	SCE	API 610 (OH2)	
Vertical In-Line Pumps	SPI	API 610 (OH3)	
	IVP / IVP-CC	HI design (OH4 / OH5)	
	IIL	HI design (OH5) Dimensionally compliant with ANSI B73.2	
	SPN	API 610 (OH5)	





BETWEEN BEARING PUMPS

CATEGORY		RP MODEL	DESIGN STANDARD	
1 and 2 stage	Axially split	HSC / HSD / HSL HSR / ZW	HI design (BB1)	
		HSM	HI design (BB3)	
		ZM / ZMS ZLM / ZME	API design (BB1)	
	Radially split	HVN / J	API design (BB2)	
		RON / RON-D	API design (BB2)	
Multi-stage	Axially split	SM / SM-I	API design (BB3)	
		JTN	API design (BB3)	
	Radially split <i>single casing</i>	GP	API design (BB4)	
	Radially split <i>double casing</i>	A LINE	API design (BB5)	





VERTICAL PUMPS

CATEGORY		RP MODEL	DESIGN STANDARD	
Single casing	Diffuser	VTP	HI & API 610 (VS1)	
		VCT	HI & API 610 (VS1)	
		HQ	HI & API 610 (VS1)	
		VLT	HI & API 610 (VS1)	
	Volute	DSV / DX	HI & API 610 (VS2)	
	Discharge through column – Axial flow	VAF	HI & API 610 (VS3)	
Separate discharge line	VSP / VSP-Chem	HI & API 610 (VS4)		
Double casing	Diffuser	VLT / VMT	HI & API 610 (VS6)	
	Volute	DSV / DX	HI & API 610 (VS7)	
Submersible pumps		SMF	HI design (OH8A)	
		VLT-Sub / VTP-Sub	HI design (VS0)	





OUR PUMPS

SPECIAL SERVICE PUMPS

CATEGORY	RP MODEL	DESIGN STANDARD	
Pitot tube pumps	COMBITUBE	HI design	
Reciprocating pumps	RDP	API 674 ISO 13710	
Vertical turbine generator	VTG	HI design (VS6)	
Barge	LS BARGE	HI design	
Floating dock pumps	ZVZ	HI design	
	LVZ	HI design	
Cryogenic pumps	SVNV	-	
	VTG Cryogenic	-	
	VLT Cryogenic VLTV	-	
Pre-packaged fire pump systems	Fire systems incorporate pumps, drivers, control systems and pipework in a single container. They can be skid mounted, with or without enclosure and supplied with electric motor or diesel engine.	NFPA-20-850 UL and FM approved components	

